


FLOOR LEVELING OPTIONS

There are multiple ways to level your floor frame. Our recommended leveling method is shown below.
Leveling materials are not included in this kit.

PREFERRED METHOD - 4x4 TREATED RUNNERS

(3) Earth Anchors per side
(See Page 8)



MATERIAL REQUIRED

x2 4" x 4" x 12' (10 x 10 x 366 cm) Treated Lumber

Fasteners for Frame to 4"x 4".


(3" Screws shown as one option.) Minimum (40) 3" screws / exterior grade.



Use only wood treated for ground contact and fasteners approved for use with treated wood.



Always support frame seams.



LEVELING METHODS

- Level under 4x4 runners only.
- Locate leveling material 12" from ends of runners and no more than 48" apart.
- Asphalt shingles should be used between 4x4 runners and blocks or treated lumber. Never use shingles in direct contact with ground.
- For best results and aiding in water drainage use gravel under each concrete block.

LEVELING MATERIALS

- Gravel
- Solid Masonry Blocks in 1", 2", 4" or 8" thickness
- 2x4 Treated Lumber
- Asphalt Shingles



Leveling higher than 16" not recommended.

CONCRETE

- If you are building your shed on a concrete foundation see the following page.